

Differences Between the 84499A & the 84499 FIND-R-SCOPE®

The 84499A FIND-R-SCOPE®

I. The objective mount is not removable from the instrument housing.

II. The eyepiece insert is gray in color and is not removable from the instrument.

III. The image converter tube (6) diameter at the front is approx. 34.5 mm, or 1.36" P/N 61896.

IV. Other objectives can not be readily mounted on this unit.

Part Names Common to Both Models

- | | |
|--|---|
| <ul style="list-style-type: none"> 1. Eyepiece with rubber shield 2. Master ON/OFF power switch 3. High voltage power supply 4. "C" cell battery | <ul style="list-style-type: none"> 5. Battery end cap assembly 6. Image converter tube 7. Objective lens assembly 8. Eyepiece insert. |
|--|---|

The 84499 FIND-R-SCOPE®

I. The objective mount is removable from the instrument housing, and a portion of it is black.

II. The eyepiece insert (8) is black in color, is attached with screws and is removable from the instrument housing.

III. The image converter tube (6) diameter at the front is approx. 48 mm, or 1.89" P/N 82359.

IV. Any "C-mount" objectives can be used with this viewer via the optional "C-mount" adapter, including zoom lenses.

Model 84499

Note: The optional "C-mount" adapter P/N 85299 is not part of the 84499 package.